

Release Notes for Shift Addresses 5.0 (Build 1468)

1 General information

Please check for new App versions!

1.1 Operating systems

- Microsoft Windows 8.1 x32/x64
- Microsoft Windows 10 x32/x64

1.2 Installation

You need ETS5 from version **5.7.2**. ETS4 and earlier ETS5 versions are **no longer supported**. If you have an older version, please uninstall this one first via setting panel in ETS

2 Important changes since previous release

2.1 Changes since Release 5.0.1435.0.

- FIX: limit for gap adjusted

2.2 Changes since Release 4.0.1387.0.

- FIX: Arrangement of the control elements improved, command "Execute" additionally possible via function key "F9"
- App does not run in ETS4 anymore

2.3 Changes since Release 4.0.1068.0.

- FIX: Scrollbar for too short or too narrow operation window
- FIX: Shift addresses by rules: refresh button from ETS project
- FIX: Shift addresses from file: required main/middle groups and areas/lines can be inserted automatically via option

2.4 Changes since Release 4.0.441.0.

- NEW: In ETS5 devices with additional individual addresses will be supported
- NEW: source and target addresses can be read from a file
- NEW: advanced rules for moving: define gaps

2.5 Changes since Release 4.0.350.0.

- FIX: In ETS5.0.6 a group address could not be moved into another main group or middle group or group range without changing group address part of address (e.g. 1/250 -> 2/250)
- FIX: Formatting free group address style in preview
- Adaption to ETS5 layout

2.6 Changes since Release 4.0.261.0.

- Works also in ETS5

2.7 Changes since Release 4.0.47.0.

- FIX: even for two level group address style the upper limit of start address was 255.